

Dear Mobi Customer,

Your registration information has been received. Please print or copy and save this email for future reference. Below are instructions on how to download and install the USB Driver for your MobiCam DXR and the MobiCam Anywhere Software.  
Instructions

### **To install the MobiCam DXR driver**

**Step 1** Click on the following link to download the installation files to your computer [www.getmobi.com/drivers/mobicamdxr.exe](http://www.getmobi.com/drivers/mobicamdxr.exe)

Please note the file can take several minutes to download depending on your connection speed.

**Step 2** Click Run when prompted to Run or Save the files

**Step 3** Click on Browse and select a location to save the files. Please be sure to select a location that is easily accessible and note the location.

**Step 4** Click Unzip

**Step 5** After the unzip has completed close the unzip window and navigate to the location where the files have been saved and open the MobiCam DXR folder

**Step 6** Double click on the MobiCam DXR driver to install the USB driver and follow the prompts

**Step 7** Plug in your MobiCam DXR monitor with the provided USB cable and wait for your computer to recognize the driver

Note: In case the driver was not recognized after the USB cable has been plugged in, please restart your computer

### **To Install the MobiCam Anywhere Software**

Please note if a copy of this software is already installed on your computer you do not need to proceed further.

**Step 1** Open MobiCam DXR folder

**Step 2** Open the MobiCam Anywhere Software folder

**Step 3** Double click on the MobiCam Anywhere software setup and follow the prompts

**Step 4** When prompted enter the registration code which was emailed when you registered your product

To use the MobiCam Anywhere Software please refer to the enclosed manual located in the MobiCam DXR folder labeled MCA Software Quick Start.

If you should have any questions please contact customer service at 877-662-4462.